

Magnetic Dry-Erase 17.5" x 13.5" Weekly Planner for the Refrigerator



- 1 Planner (17.5" x 13.5" Horizontal)
- 8 Whiteboard markers
- 1 Magnetic eraser
- 1 User instructions

- **Free bonus!**

3 magnetic blank boards (5" x 8")

Note: If the board doesn't fit your fridge, we also have a vertical version of the weekly planner.

Guideline #1 – Wipe Before First Use:



Please take **1-2 minutes** and do a one-time thorough wipe off on **the entire surface of the boards**. You can use the included eraser, a dry paper towel or a kitchen cloth. This will prevent the possible remaining residues on the board from causing the ink to run before it gets dry.



If, during usage, the ink runs in some specific area or spots, just give this area a good wipe to solve this immediately.

Guideline #2 - Use the board as dual weekly

② USA AS DUAL WEEKLY



Plan two weeks ahead! You can easily divide the weekly planner into a dual weekly board.

Add dates and use different colors of the 8 included markers to separate weeks, tasks and different people in the house.

Use the 3 small bonus boards as reinforcement for general lists like To-Do and grocery list.

Instructions

BEFORE FIRST USE:

- 1. Please Check if your fridge is magnetic** - If regular magnets stick to your fridge, this magnetic board will too. The front of some stainless steel fridges is magnetic and some are not. Please check yours!
- 2. Please check if your fridge has the required space** - the intended fridge door/side should have room for the large magnetic board, which is 17.5" in width and 13.5" in height, and for the other included magnetic items (5" x 8" small boards, markers and eraser). They need to lie on a flat surface, without any bumps / fridge logo.

INSTALLATION:

- 1. Take the boards out of the nylon bags** - Please make sure to keep the bags out of children's reach, as a safety precaution against choking.
- 2. Clean the mounting area** - Please wipe off any dirt or dust from the intended mounting space on your fridge and let it dry completely.
- 3. Wipe the board clean before first use** - Quickly wipe off the boards with a dry paper towel - this needs to be done only one time, before the first use, because the boards were kept in nylon bags for some time. We want to make sure they are clean and smooth for best dry-erase performance.
- 4. Attach the magnetic markers and eraser to an area outside of board areas** - Please place these items directly on the fridge surface but outside of the magnetic board areas for the best magnetic pull force.

PROPER USE:

- 1. Use only proper markers, and keep them closed when not in use** - Please make sure you are using only dry-erase whiteboard markers. For longer durability, make sure to put cap back on immediately after using each marker.
- 2. Erasing the boards** - Markers can easily be erased from the boards, using the eraser included or even a dry paper towel or cloth. If marker ink remains on the boards for longer than about 40 days, you may find it too dry for a quick wipe. In this case, the best option is to wipe it off with some deodorant or alcohol, using a dry paper towel and the ink will come off immediately.
- 3. Cleaning the Eraser** - After multiply uses, the eraser might need some clean up itself. Quickly rinse it with water and gently rub the eraser surface with your finger until all the marks come off. Once you finish let it dry completely.

We appreciate your business!

Sincerely,

Christa

HMmagnets Founder



A handwritten signature in blue ink that reads 'Christa' with a long horizontal line extending to the right.